


Nicor Cable Retrofit Procedures

FOR MODEL UDA “UNIVERSAL DUPLEXER FOR AMI/AMR”



In Applications where the UDA “UNIVERSAL DUPLEXER” is to be retrofitted with Nicor Pigtail Cables, These Wiring Procedures Should be Followed:



1. The **Female Nicor Cable** Should Be Run Through the Middle Cable Gland.
2. The **Female Nicor Cable’s** Internal Conductor Wires Should Be Connected to the UDA Terminal Block as Follows:
 - 5 - RED
 - 6 - GREEN
 - 7 - BLACK
3. The **Male Nicor Cable** Should Be Run Through the Right-Most Cable Gland.
4. The **Male Nicor Cable’s** Internal Conductor Wires Should Be Connected to the UDA Terminal Block as Follows:
 - 8 - RED
 - 9 - GREEN
 - 10 - BLACK
5. Utility Hookup:

Female Nicor Cable ↔ **Water Meter**
Male Nicor Cable ↔ **AMI/AMR MTU**