

Application Note 028
 Version 001
 14 January 2020

Nicor Cable Connection to the SDAW “AMI Duplexer for SCADA Systems, Wall-Mount Version”.

The purpose of this Application Note is to illustrate the wiring diagram for connecting the Nicor Cable Kit to the Model SDAW “AMI Duplexer for SCADA Systems, Wall-Mount Version”.

The Wide (Female) Nicor Cable should be run through the Middle Cable Gland, and the Narrower (Male) Nicor Cable should be run through the Right Cable Gland. The Female Cable has 3 conductors, [Red,Green,Black]. These should be connected to SDAW terminals [4,5,6] respectively. The Male Cable also has 3 conductors, [Red,Green,Black]. These should be connected to SDAW terminals [7,8,9] respectively.

